

## EZ9Plus & EZ11Plus User Self Help:

"Water in the chamber Icon displayed"













Problem:
This icon is displayed if the electrode senses water in the chamber after the cycle has stopped.















DO NOT open the door, water will spill out.

What to do: Run a new cycle to drain the chamber














## Problem:

The water electrode may be dirty giving a false reading.

What to do: Clean the electrode














## Problem:

Instrument hanging off a tray maybe touching the electrode

What to do:
Make sure instruments stay
on the tray









